



Nest Instructions



Brief Introduction

Our nest swing is a main attraction for any playground or playset.
The swings are delivered with suspension ropes and short link chains.



Basic information

Recommended for children 3+ years.

Good safety practices should be followed at all times.


Read all instructions before using our products.

Maximum weight capacity: 1100lbs/500 kgs



Suspension

It is recommended to attach the swing to 2 pivot points with suspension ropes and chains angled outwards slightly. It's possible to attach it to a single point to allow spinning.



(H=Height of support from safety surface, S=Swing seat above the safety surface)

Technical Data
H=2.2-2.3 meters (7 feet)
S=0.5 meters (Min. of 12 inches)

The swing should be installed only by a licensed playground installer who is trained and certified on the relevant playground standards.

The swing should be setup above a soft surface, that is a suitable height that is easy to get on, and reduces the risk of falling a minimum of 12 inches from the nest to the surface. The swing must be placed in an area that is free from any obstacles that could either A) hit the swing seat or B) cause someone who is hit by the swing seat to collide into another object. The hanging points must be strong enough to support 1300 lbs or more. We provide many different kinds of swing hangers to support the Nest.



Multi-dimensional swing hanger

Safety Tips

The Nest swings are very heavy, therefore it will have a lot of momentum when swinging. Make sure to keep the play zone clear when swinging. Avoid sitting in a way which could lead to someone falling off the swing. Do not jump off the moving swing. It may be unsafe to use when wet and in case of slipping. Wear only safe clothes: no scarves, or clothing with drawstrings, or anything that could lead to a choking hazard. Do not attach additional objects to the swing when playing. Sitting and laying on the seat is much safer than standing.

Maintenance

Avoid holding sharp items that could damage the swing. Being set up under a shade can be optimal, however it is not necessary. Regularly check the swing seat, ropes, hangers, chains for wear and tear. Regularly lubricate the metal parts like swing hangers if necessary. Avoid damaging the tape which covers the ends the edge of the seat.

